








- CARE AND MAINTENANCE -



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

The product can be cleaned with a soft damp cloth and mild detergent, or a dry microfibre cloth. Do not use alcohol or any other solvents to clean the product and avoid using abrasive or rough sponges. Ensure that the power supply has been turned OFF before cleaning the product.

Our Care & Maintenance offers guidance for optimal maintenance of your HAY product. It includes advice and instructions on cleaning and caring for specific materials to prolong the life of your lighting.



Please find our Care & Maintenance guide by scanning the QR code




You can find more relevant information on Host Portable Lamp by scanning the QR code



Havnen 3 8700 Horsens Denmark
+45 4282 0282 / hay@hay.com

www.hay.com

HOST PORTABLE LAMP



DESIGN BY HAY

HAY

- TECHNICAL DATA -

This product is fitted with a low voltage, replaceable LED light source designed for this portable lamp.

FITTING TYPE | Low voltage LED panel

POWER (W) | 8 W Lamp (2W LED)

COLOUR TEMPERATURE | 2700K warm white

For a replacement LED light source, please contact HAY or an authorised dealer. HAY will not accept any responsibility for any accidents, injuries or damages that occur due to the use of incorrect light source.

- Max. charge voltage of battery: 4.25V
- Max. charging current: 2000mA
- Max. discharge current: 640mA

- ATTENTION -

The product must not be modified in any way. HAY accepts no responsibility for any products that have been modified or tampered with. If the external USB charging cable is damaged it should be replaced immediately. This lamp is designed for indoor and outdoor use. HAY recommends that the lamp is not kept outside while raining.

When charging the battery, use a USB power source/driver with low voltage (SELV) output that has a constant voltage of 5VDC and limits the output current to maximum of 2A, according to IEC/EN 61347-2-13. The battery shall only be charged in a 10-25 °C ambient temperature. To extend battery life, it is recommended to regularly charge it with the supplied USB cable.

For instructions on how to replace the battery in the lamp, scan the QR code in this manual for instructions. You can also find information about battery replacement at hay.com. The battery contained in this luminaire shall only be replaced by the manufacturer or their service agent or a similarly skilled person*.

NOTE | This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a different circuit to the one the receiver is connected to.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION | Changes or modifications to this unit not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

WARNING | When using outdoor use portable luminaires, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury, including the following:

- Use only three-wire outdoor extension cords that have three-prong grounding plugs and grounding receptacles that accept the appliance's plug.
- Ground Fault Circuit Interrupter (GFCI) protection is to be provided on the circuit(s) or outlet(s) to be used for the wet location portable luminaire. Receptacles are available having built-in GFCI protection and are able to be used for this measure of safety.
- Use only with an extension cord for outdoor use, such as an extension cord of cord type SEW, SEOW, SEOOW, SOW, SOOW, STW, STOW, STOOW, SJEW, SJEOW, SJEOWW, SJW, SJOW, SJOOW, SJTW, SJTOW, or SJTOOW.
- Suitable for damp and wet locations.
- Do not submerge.

* Replacement services are not provided by HAY